

Leben im Bad
Living bathrooms



Ceramic surfaces



Care instructions
(without WonderGliss)

en

Care instructions

Ceramic has many positive properties: it is resistant to heat and cold, abrasion and scratch-resistant, light-fast and hygienic. As a natural raw resource, it is completely safe to use and also extremely durable.

Please observe the following cleaning and care instructions so that you can enjoy your ceramic for as long as possible:

Which cleaner?

NOTICE!

Damage to the surface due to incorrect cleaning!

- Only use cleaners and equipment that are suitable for the application.
- Follow the manufacturer's instructions for the cleaner.
- **Never** mix cleaners.

A mild commercially available sanitary cleaner is suitable for **daily cleaning**, **limescale stains** can be removed using an acidic vinegar or citrus based cleaner (pH value 1-4). The harder the water is, the greater the quantity of cleaner that should be used.

Metallic marks resulting from use (black dots/lines, e.g. due to rubbing of rings) cannot be removed using mild cleaners. Only treat the affected area with Stahlfix (German brand) or equivalent stainless steel cleaner, car polish or a ceramic hob cleaner.

How often?

Regularly clean the coated surface, or clean immediately if soiled. If the cleaning is not carried out regularly enough, soiling, e.g. limescale and soap stains, cosmetic residues, rust and mould, may become visible and subsequently more difficult to remove.

How?

- > Clean the surface with a soft clean cleaning cloth and warm water.
- > When tackling stubborn dirt, wait a few minutes to allow the cleaner to take effect.

Tip! An advantage of using gels and foaming cleaners is that they also adhere well to sloping surfaces. You can also soak a cloth in the cleaner then place it on the soiled area.

- > Rinse with clean warm water to remove all traces of the cleaner.
- > Dry the surface.

Leben im Bad
Living bathrooms

DURAVIT

Chrome



Care instructions

Care instructions

Chrome-plated surfaces

Chrome-plating a surface protects it from mechanical and chemical damage.

Incorrect cleaning may damage the chrome coating and lead to discolouration and corrosion damage. Please observe the following cleaning instructions so that you can enjoy your product for as long as possible.

Which cleaner?

Use washing-up liquid for daily cleaning; limescale stains can be removed using a commercially available citrus-based sanitary cleaner.

How often?

Clean the coated surface daily or immediately if soiled.

How?

NOTICE!

Damage to surface due to incorrect cleaning!

- Only use cleaning agents and equipment that are intended for this application.
- Follow the cleaning manufacturer's instructions.

- Do **not** use cleaners that
 - contain hydrochloric acid, formic acid or acetic acid
 - contain phosphoric acid or chlorine bleach
 - contain sulphur
 - have an abrasive effect
- **Never** mix cleaners.
- Do **not** use cleaning equipment with an abrasive effect (e.g. pad sponges or micro fibre cloths).
- **Do not** use steam cleaners as the high temperatures could damage the product.
- Spray the spray cleaner onto the cleaning cloth, never directly onto the product. The spray can penetrate openings and gaps and cause damage.

Take note of the cleaning instructions and the time taken to work under the conditions and do not allow the cleaner to remain on the surface longer than necessary.

- > Clean the surface with a soft cleaning cloth and a little water.
- > Remove more stubborn stains by applying the cleaner to a soft cleaning cloth and treating the area.
- > Rinse with clean water to remove all traces of the cleaner
- > Dry the surface.

de Reinigung und Pflege

HINWEIS! Verwenden Sie nur von Duravit empfohlene Reinigungsmittel. Andere Reinigungsmittel können zu Beschädigungen des Materials führen.

ACRYL

Oberflächenpflege

In der Regel lässt sich Acryl mit einem weichen Tuch und etwas Wasser einfach sauber halten. Vermeiden Sie unbedingt Scheuermittel. Stärkere Verschmutzungen können auch mit warmen Wasser und einem flüssigen Reinigungsmittel, Geschirrspülmittel oder Seifenlauge entfernt werden.

Für die gelegentliche Grundreinigung und zur Entfernung hartnäckiger Flecken empfehlen wir das Duravit Pflegeset für Acryloberflächen (Best.-Nr. 790301 00 0 00 0000).

Kalkflecken

Kalkablagerungen lassen sich sehr einfach mit Branntweinessig und Wasser entfernen, dabei aber unbedingt die Armaturen aussparen. Nach Behandlung mit klarem Wasser gut nachspülen.

Beschädigungen

Kratzer und andere oberflächliche Beschädigungen lassen sich am Besten mit dem Duravit Pflege- und Reparaturset für Acryloberflächen (Best.-Nr. 790302 00 0 00 0000) beseitigen.

MÖBELVERKLEIDUNG

Hartnäckige Verschmutzungen mit heißem Wasser und evtl. etwas Spülmittel entfernen.

HOLZAUFLEGER

Holzaufleger nach jeder Benutzung der Wanne reinigen und trocknen. Keine aggressiven Reinigungsmittel verwenden, insbesondere keine Scheuermittel.

STEINE

Wir empfehlen, die Steine nach jeder Benutzung der Wanne kurz mit Wasser abzuspülen, damit Seifen- und Schaumreste von den Steinen gelöst werden.

RUHEDECK

Keine Scheuermittel, keton- oder acetathaltige Reinigungsmittel verwenden. Polsterstoff mit einem Mikrofasertuch und Wasser reinigen. Hartnäckige Verschmutzungen mit heißem Wasser und etwas Spülmittel, alkoholhaltigem Reinigungsmittel oder Waschbenzin entfernen.

DESINFEKTION DES WHIRLSYSTEMS

Duravit Whirlsysteme sind serienmäßig mit einer aufwändigen Restwasserentleerung ausgestattet.

Vor längeren Standzeiten sollte das System mit Duravit Desinfektionsmittel (Best. Nr. 790300 00 0 00 0000) desinfiziert werden um Keimbildung vollständig auszuschließen.

en Cleaning and Care

NOTE! Only use cleaning substances recommended by Duravit. Other than those can cause damage the material.

ACRYLIC

Surface cleaning

Clean the surface with a soft cloth and soapy water. Do not use abrasive cleaning liquids. More resistant stains can also be removed with warm water and a mild, liquid detergent or soap sud.

For removing stains we advise using the Duravit care kit for acrylic surfaces (Art. no. 790301 00 0 00 0000).

Lime stain

Lime stains can be taken off with brandy vinegar and water. After treatment rinse with clear water.

Damage

Cleaning substances other than those recommended by Duravit can cause damage the material. Scratches and other superficial damage can be corrected using the Duravit care and maintenance kit for acrylic surfaces (Art. no. 790302 00 0 00 0000).

FURNITURE PANEL

Remove stubborn dirt with hot water and a few drops of washing up liquid.

WOODEN INLAYS

Clean the wooden inlays with water after each bath and stand up the inlay to let dry. Do not use any aggressive cleaning agent, particularly no scouring agent.

STONES

After each bath rinse the stones briefly with water after each bath, to remove soap and bubble bath residue.

RELAXING DECK

Do not use abrasive cleaning liquids and detergents whith acetate or ketone. Clean it with a microfibre cloth and water. For removing tenacious stains use washing up liquid, alcoholic detergent or cleaning solvent.

DISINFECTION OF THE WHIRLSYSTEM

Duravit Whirlpools feature full system drainage.

To ensure hygiene and long productive life we recommend the use of Duravit disinfectant model (Art.no. 790300 00 0 00 0000).

Duravit AG

Werderstr. 36

78132 Hornberg

Germany

Phone +49 78 33 70 0

Fax +49 78 33 70 289

info@duravit.de

www.duravit.de



We reserve the right to make technical improvements and enhance the appearance of the products shown.